Signicade Deluxe

PLASTICADE®

Change your sign often ... you can do it in seconds

- Change signs in seconds
 - "Quick-Change" feature, signs easily slide in and out
 - use Coroplast signs or other material 3/16" or less
- "Stay Tabs" assure sign stays securely in place
- No Maintenance
 - all plastic, use indoors and out
- No tape, Velcro[®], or screws needed
 - eliminates fastener damage to signs
- Internally weight with sand
 - ballasting columns, add sand to each leg
- Hinges lock in open position
 - prevents over-extended sign faces

"Quick-Change" Feature

Now In

Our Premier Sign Stand



Patented slot design -just slide in a sign



securely in place

Holds Two 24"W x 36"H Signs

Signicade Deluxe

OUTSIDE DIMENSIONS: 46.125"H x 27"W x 3.125"D


DIMENSIONS OF RECESSED SIGN AREA: 35.125"H x 24.375"W

WEIGHT: 20 lbs.

COLORS: White and Black, Custom Colors Available

2 SIGNS PER FRAME

Holds Signs 24"W x 36"H (up to 3/16" thick)



Sand Ballasting Instructions




Each sign frame has four fill holes, two on each side of the frame.


Remove plug from fill hole and fill each hole with sand. 2.5 lbs. of sand per hole for a total of 10 lbs. per sign frame is recommended.

Play sand is suggested for ease of filling.


Sign Insertion Instructions:




1. Slide sign down through the tabs



2. Slide through, pulling sign in front of bottom slot until sign hits the ground



3. Push sign up into top slot




4. Slide sign down into bottom slot

HDPE

MADE IN THE USA
US PATENT 7,337,569

PLASTICADE





or a Marker Board...





7700 Austin Avenue Skokie, IL 60077 phone (800) 772-0355 fax (847) 966-8074 www.plasticade.com