



ADVER-FLAG

FEATHER AND TEARDROP **GROUND STAND** ASSEMBLY INSTRUCTIONS









MADE IN CANADA

PARTS



ASSEMBLY

<p>1. Stack poles together to assemble (DO NOT TELESCOPE POLE). Once assembled, pull flag over pole.</p> 	<p>2. Take the cord and fold it in half, looping it through the grommet and threading the rest of the cord through the loop.</p> 
<p>3. Pull flag and cord down until snug on pole. Once placement is decided, pull cord down toward the anchors, and wrap tightly under both anchors until secure.</p> 	<p>4. Next, setup the ground stand system by placing the legs across one another with the nut of the leg facing the ground.</p>  <p>bottom top</p>
<p>5. With the nut on the bottom of the stand, screw the Ground Stand Stem into place securing both legs together in an "X" position.</p>  <p>(Optional) Heavy Duty Water Bag Provides extra stability.</p>	<p>6. Place the Pole Adapter into the Ground Stand Stem, and then place the flag onto the Pole Adapter. Note: If using the 24" Pole Adapter Extension, insert it into Ground Stand Stem, then place the Pole Adapter and flag atop of the Extension.</p> 

! GUIDES AND PRECAUTIONS !

- Flag system may be damaged in winds exceeding 35 km/hr. PLEASE DO NOT USE IN INCLEMENT WEATHER.

- Do not use near overhead wires, if not used correctly it may result in injury or death.

- Must have rotational movement. Keep at least 5ft away from any objects to increase life expectancy of flags. IE Fences, Trees, Buildings Etc.